



SERVICE MAINTENANCE SUGGESTION			
NUMBER	DESCRIZIONE	DESCRIPTION	CYCLES
3	Coperchio Masse Battenti alluminio	Aluminium clutch cover	1500
3C	Coperchio Masse Battenti carbonio	Carbon clutch cover	750
4	Cuscinetto combinato	Combined bearing	250
6	Albero portabussola	Anvil shank	750*
9	Innesto	Clutch plate	250*
12	Volano	Clutch housing	750*
26	Rotore	Rotor	500*
27	Paletta Motore	Motor Vane	250

\* Unless 250 cycles NDT finds cracks.

NUMBER	CODE	DESCRIZIONE	DESCRIPTION	N.
01	D.09.01.0004	Vite TCEI	Socket Head Cap Screw, Clutch Cover	4
02	D.09.06.0023	Rondella Nord-Lock NI6 Con Delta Protekt	Lock Washer	4
03	D.01.03.0085	Coperchio Masse Battenti	Clutch Cover	1
03C	D.01.03.0082	Coperchio Masse Battenti Fibra Carbonio	Clutch Cover (Carbon Fiber)	1
04	D.01.15.0064	Cuscinetto Combinato	Combined Bearing	1
05	D.01.15.0035	Cuscinetto Reggispinta	Needle Thrust Bearing	1
06	D.01.04.0115	Albero 1" - C/Foro - S/Gola Anello - Corto	1" Square Drive Shaft	1
07	D.01.12.0025	Molla	Clutch Spring	1
08	D.01.05.0008	Albero Scanalato	Clutch Shaft	1
09	D.01.06.0040	Innesto	Clutch Plate	1
10	D.01.07.0017	Camma	Cam, Clutch	1
11	D.01.09.0011	Sede Albero Scanalato	Bushing, Clutch Housing	1
12	D.01.08.0049	Volano	Clutch Housing	1
13	D.01.11.0015	Perno Per Rullo Volano	Pin, Roller	1
14	D.01.10.0003	Rullo Volano	Roller	1
15	D.01.15.0003	Cuscinetto A Sfere	Ball Bearing	1
16	L.01.0117	Impugnatura 72° Vern. Grigio	Gun Body	1
17	D.09.01.0035	Vite STEI	Set Screw	1
18	D.01.25.0023	Filtro Aria	Air Filter	1
19	D.01.25.0024	Filtro Aria	Air Filter	1
20	D.09.01.0133	Vite Tspei M3x6	Socket Countersunk Head Screw	6
21	D.09.01.0132	Vite	Screw	3
22	D.01.15.0018	Cuscinetto A Sfere	Ball Bearing	1
23	L.08.0111	Flangia Motore Anteriore	Front End Plate	1
24	D.09.12.0043	Rullo a Testa Piana	Roller	1
25LH	D.01.18.0071	Cilindro LH Hurricane	Main Motor Housing - LH	1
25RH	D.01.18.0071	Cilindro RH Hurricane	Main Motor Housing - RH	1
25UH	D.01.18.0072	Cilindro UH Hurricane	Main Motor Housing - UH	1
26	D.01.30.0096	Rotore Hurricane	Rotor	1
27	D.01.19.0054	Paletta	Vane	7
28	L.08.0089	Flangia Motore Posteriore	Rear End Plate	1
29	D.09.12.0010	Spina Fermo Motore Posteriore	Pin	1
30	D.01.15.0019	Cuscinetto a Sfere	Ball Bearing	1
31	D.01.62.0001	Vite Ritegno Assiale	Axial Retention Screw	1
32	D.01.17.0111	Guarnizione Motore	Rear Gasket	1
33	D.09.06.0022	Rondella	Lock Washer	4
34	D.09.01.0057	Vite TCEI	Socket Head Cap Screw	2
35	D.09.01.0058	Vite TCEI	Socket Head Cap Screw	2
36	T.02.0030	Etichetta Adesiva Impugnatura	Handle Sticker	1
37	B.23.0156	Kit Oliatore	Oiler Kit	1
38	D.01.33.0042	Corpo Ingresso Aria	Reducer, Air Inlet	1
39	D.09.02.0060	O-Ring	O-Ring	1
40	D.01.25.0005	Filtro Aria	Air Filter	1

<b>41</b>	D.01.12.0060	Molla Valvola	Valve Spring	1
<b>42</b>	D.01.22.0016	Sfera Acciaio	1Steel Ball	1
<b>43</b>	D.09.02.0092	OR Sintek	Valve Seat	1
<b>44</b>	D.01.31.0041	Perno Valvola	Valve Pin	1
<b>45</b>	D.09.03.0001	Spina Elastica	Pivot Pin, Trigger (Long)	2
<b>46</b>	D.01.21.0028	Leva Avviamento	Trigger	1
<b>47</b>	D.01.02.0195	Coperchio Motore 3Port	Motor Cover	1
<b>48</b>	D.09.01.0011	Vite STEI	Set Screw	2
<b>49</b>	D.01.12.0052	Molla Inv. Rigida	Spring	2
<b>50</b>	D.01.31.0037	Perno Invertitore	Pin, Rotation Reverser	2
<b>51</b>	D.09.01.0134	Vite	Socket Countersunk Head Screw	1
<b>52</b>	D.01.13.0094	Boccola Coperchio	Bushing	1
<b>53</b>	D.01.35.0052	Boccola Valvola Spool	Bushing	1
<b>54</b>	D.01.25.0020	Filtro Aria	Air Filter	2
<b>55 LH</b>	D.01.14.0057	Invertitore 3Port LH	Rotation Reverser Shaft - LH	1
<b>55 RH</b>	D.01.14.0058	Invertitore 3Port RH	Rotation Reverser Shaft - RH	1
<b>55 UH</b>	D.01.14.0056	Invertitore 3Port UH	Rotation Reverser Shaft - UH	1
<b>56</b>	D.09.02.0097	O-Ring	O-Ring Bushing Rotation Reverser Shaft	2
<b>57 LH</b>	B.31.0010	Corpo Fast Reverse LH Blu	Fast Reverse System LH	2
<b>57 RH</b>	B.31.0009	Corpo Fast Reverse RH Rosso	Fast Reverse System RH	2
<b>57 UH</b>	B.31.0013	Corpo Fast Reverse UH Nero	Fast Reverse System UH	2
<b>58</b>	D.01.02.0196	Coperchio Motore 2Port	Motor Cover - 2Port	1
<b>59</b>	D.01.62.0003	Grano Spec.	Grub Screw	2
<b>60</b>	D.01.12.0080	Molla Coperchio 2 Port	Cover Spring - 2Port	2
<b>61</b>	D.01.31.0069	Perno Coperchio 2 Port	Cover Pin - 2Port	2
<b>62 LH</b>	D.01.14.0068	Invertitore 2Port LH	2 Port Welded Spool - LH	1
<b>62 RH</b>	D.01.14.0069	Invertitore 2Port RH	2 Port Welded Spool - RH	1
<b>62 UH</b>	D.01.14.0070	Invertitore 2Port UH	2 Port Welded Spool - UH	1
<b>63</b>	D.09.02.0060	O-Ring	O-Ring	2
<b>A</b>	D.01.01.0232	Impugnatura Completa 72° Vern. Grigio	Whole Gun Body-Grey	1
<b>B</b>	D.01.37.0088	Coperchio Masse Battenti Completo Alluminio	Whole Hammer Case With Bearing - Aluminum	1
<b>B</b>	D.01.37.0089	Coperchio Masse Battenti Completo Carbonio	Whole Hammer Case With Bearing - Carbon	1
<b>C</b>	D.01.16.0086	Flangia Motore Anteriore Completa	Front Motor Housing Complete	1
<b>D</b>	D.01.16.0081	Flangia Motore Posteriore Completo	Rear Motor Housing Complete	1
<b>E LH</b>	D.01.49.0081	Coperchio Motore Completo 3Port LH	Whole motor cover LH 3Port	1
<b>E RH</b>	D.01.49.0082	Coperchio Motore Completo 3Port RH	Whole motor cover RH 3Port	1
<b>E UH</b>	D.01.49.0083	Coperchio Motore Completo 3Port UH	Whole motor cover UH 3Port	1
<b>F LH</b>	D.01.49.0084	Coperchio Motore Completo 2Port LH	Whole motor cover LH 2Port	1
<b>F RH</b>	D.01.49.0085	Coperchio Motore Completo 2Port RH	Whole motor cover RH 2Port	1
<b>F UH</b>	D.01.49.0086	Coperchio Motore Completo 2Port UH	Whole motor cover UH 2Port	1
<b>G</b>	B.23.0147	Kit Ingresso Aria Hurricane	Air Inlet Kit	1
<b>H</b>	B.23.0170	Kit Assistenza Hurricane	Service Kit Hurricane	1